



EXTRA BRACING ACROSS OPENINGS AS APPROPRIATE

TIMBER BLOCKS FIXED TO BRACE AS APPROPRIATE, PROVIDING SUPPORT TO FORMWORK AT OPENING HEAD

TIMBER FORMWORK SHOULD BE BRACED AS DETERMINED ON SITE

REBATE IN FLOOR SLAB FOR DOOR

SECURELY FIX BRACE & SUPPORT TO FLOOR



Title:

**CONSTRUCTING WINDOW/DOORS
BRACING OPENINGS**

Cad ref N°: **CWD-BO**

These details are intended to assist the user in the construction of Ambionse insulated concrete formwork structures

Drawn:
C COTTLE

Scale:
1:20 @ A4

Date:
NOV 2005